RBH ACCESS CONTROL SOLUTION

Controller Compatibility

RBH Controller Series

	Integra32 R5 (On prem.)	AxiomXa (On prem.)	AxiomV R4 (On prem.)	AxiomCLOUD (ACaaS)
INT-UNC100	✓	✓* (requires flash Axiom UNC100 firmware)	✓* (requires flash Axiom UNC100 firmware)	✓* (requires flash AxiomCLOUD UNC100 firmware)
AX-UNC100	✗	✓	✓	✓* (requires flash AxiomCLOUD UNC100 firmware)
UNC-500	✗	✓	✓	**forthcoming** (requires flash AxiomCLOUD UNC500 firmware)
IRC-2000	✓	✓** (requires physical Axiom NIRC firmware)	✓** (requires physical Axiom NIRC firmware)	✓** (requires physical Axiom NIRC firmware)
NIRC-2000	✗	✓	✓	✓
URC-2000	✓	✓** (requires physical Axiom NURC firmware)	✓** (requires physical Axiom NURC firmware)	✓** (requires physical Axiom NURC firmware)
NURC-2000	✗	✓	✓	✓
RC2	✗	✓	✓	✓
IOC16	✗	✓	✓	✓
IOC8	✓	✗	✗	✗
SAFESUITE (AXS-LCD)	✗	✓	✓	✗
EXTRDR	✓	✗	✗	✗
NC100 (DISCONTINUED)	✗	✗	✗	✗

* Controller firmware must be flashed by the dealer.

** Controller firmware must be physically replaced by the dealer.

Firmware is access-control-solution specific.