




Integra 32™

Single SITE, 2 Doors (All doors READER IN / RTE OUT)


Option A

- 1 x PC
- 1 x RBH-LIF-200
- 1 x IRBH-RC-2000-FR360N
(1 x IRC-2000; 2 x FR360N readers)
- nnnn x AW-PROXLINC-xx Cards



Option B


- 1 x PC
- 1 x RBH-H485-USB
- 1 x IRBH-RC-2000-FR360N
(1 x IRC-2000; 2 x FR360N readers)
- nnnn x AW-PROXLINC-xx Cards



Single SITE, 4 Doors (All doors READER IN / RTE OUT)


Option A

- 1 x PC
- 1 x RBH-LIF-200
- 1 x RBH-URC-2004-FR360N
(1 x URC-2004; 4 x FR360N readers)
- nnnn x AW-PROXLINC-xx Cards



Option B

- 1 x PC
- 1 x RBH-H485-USB
- 1 x RBH-URC-2004-FR360N
(1 x URC-2004; 4 x FR360N readers)
- nnnn x AW-PROXLINC-xx Cards







Integra 32™

Single SITE, 4 Doors (1st Door READER IN / READER OUT, All the rest READER IN / RTE OUT)



Option A

- 1 x PC
- 1 x RBH-LIF-200
- 2 x **IRBH-RC-2000-FR360N**
(2 x IRC-2000; 4 x FR360N readers)
- 1 x RBH-EXITRDR
- 1 x RBH-FR360N readers
- nnnn x AW-PROXLINC-xx Cards



Option B

- 1 x PC
- 1 x RBH-LIF-200
- 1 x **RBH-URC-2004-FR360N**
(1 x URC-2004; 4 x FR360N readers)
- 1 x RBH-EXITRDR
- 1 x RBH-FR360N readers
- nnnn x AW-PROXLINC-xx Cards



RBH Access Technologies, Inc.
60 Whitney Rd. Unit 14
Mahwah, NJ 07430, USA

www.rbh-access.com

Tel. 877.251.3550
Fax. 201.891.3420
usa.info@rbh-access.com




Integra 32™

Single SITE, 5 Doors (All doors READER IN / RTE OUT)


Option A

- 1 x PC
- 1 x RBH-LIF-200
- 3 x IRBH-RC-2000-FR360N
(3 x IRC-2000; 6 x FR360N readers)
- nnnn x AW-PROXLINC-xx Cards



Option B

- 1 x PC
- 1 x RBH-LIF-200
- 1 x RBH-URC-2004-FR360N
(1 x URC-2004; 4 x FR360N readers)
- 1 x IRBH-RC-2000-FR360N
(1 x IRC-2000; 2 x FR360N readers)
- nnnn x AW-PROXLINC-xx Cards





Integra 32™

3 SITES, 11 Doors (All doors READER IN / RTE OUT)


Office

- 1 x PC
- nnnn x AW-PROXLINC-xx Cards



Site 1

- 1 x RBH-LIF-200
- 1 x IRBH-RC-2000-FR360N
(1 x IRC-2000; 2 x FR360N readers)



Networking:
Add switches and routers as needed

Site 2

- 1 x RBH-LIF-200
- 1 x RBH-URC-2004-FR360N
(1 x URC-2004; 4 x FR360N readers)

Site 3

- 1 x RBH-LIF-200
- 1 x IRBH-RC-2000-FR360N
(1 x IRC-2000; 2 x FR360N readers)
- 1 x RBH-URC-2004-FR360N
(1 x URC-2004; 4 x FR360N readers)

