



## Integra32 kits **RBH-INT-UNC100- 122S-M45G-DNB-D**

Integra™ UNC100 Hybrid Edge 2-Door Controller Kit  
(Includes wall mount enclosure, power supply & 2 x M45G-DNB-D readers)

[www.rbh-access.com](http://www.rbh-access.com)

# RBH-INT-UNC100-122S-M45G-DNB-D



## Everything You Need in One Box

RBH all-in-one access control kits deliver fast, simple, and reliable installations—ideal for small-scale projects or enterprise-level systems. Designed to save time, reduce costs, and maximize system reliability.

### General Specifications:

- |                            |  |
|----------------------------|--|
| Integra32<br>Software (1)* | <ul style="list-style-type: none"> <li>• 64 Doors (32 two-door controllers)</li> <li>• One (1) year of Software Support &amp; Updates</li> <li>• Technical Documentation</li> <li>• Training Videos</li> </ul> |
|----------------------------|--|

- |   |   |
|---|---|
| INT-UNC100-122M<br>Universal Controller (1) | <ul style="list-style-type: none"> <li>• 2-door TCP/IP Universal Network Controller</li> <li>• 2 reader ports (Wiegand/OSDP)</li> <li>• 1 programmable RS-485 port</li> <li>• 8,000 card capacity &amp; 3,000 event log</li> <li>• Dedicated tamper input</li> <li>• 4 programmable inputs</li> <li>• 4 programmable outputs</li> </ul> |
|---|---|

- |                           |   |
|---------------------------|---|
| ENCL1-PS<br>Enclosure (1) | <ul style="list-style-type: none"> <li>• Wall mount with key lock (2 keys included)</li> <li>• Embedded 12VDC @ 2A Regulated Power Circuit with backup battery charger</li> </ul> |
|---------------------------|---|

- |                               |  |
|-------------------------------|--|
| RBH-M45G-DNB-D<br>Readers (2) | <ul style="list-style-type: none"> <li>• Standard Wiegand output</li> <li>• Mullion Mount (Compact Size)</li> <li>• Multi-Technology (MIFARE DESFire + BLE + NFC)</li> <li>• Built-in mobile credential support</li> <li>• Indoor/Outdoor capable</li> </ul> |
|-------------------------------|--|

\* Applicable for new systems only

\*\* Specifications are subject to change without notice.

### Integra 32™



Software (1)\*  
Integra32

Controller (1)  
INT-UNC100



Enclosure (1)  
ENCL3-PS



Readers (2)  
M45G-DNB-D

### Package Includes:

- Software with one year support & Updates\*
- Free Unlimited Mobile Credentials
- Wiring Diagrams
- Technical Documentation
- Training Videos

With the technology of:



Compatible with:



How to order:



RBH-INT-UNC100-122S-M45G-DNB-D



RBH Access Technologies, Inc.  
2 Automatic Road, Suite 108  
Brampton ON L6S 6K8, Canada

1-905-790-1515  
1-905-790-3680

[info@rbh-access.com](mailto:info@rbh-access.com)



[www.rbh-access.com](http://www.rbh-access.com)